

D3.F2



2009.23 (eng)

Control switch – footswitch model


Sturdy footswitch suited for both horizontally sliding (left/right) and vertically sliding (up/down) windows. The ergonomic design of the footswitch makes it easy to operate and at the same time it efficiently prevents unintentionally activation of both switches simultaneously. When pressed, the switches make a distinct clicking sound.

Connecting a footswitch as well as a hand controlled switch to a sliding window gives the operator the possibility to choose his or hers preferred method of operation. ¹

¹ In order to connect two or more control switches, a splitter for D3 control switches is required.



DESIGN



TECHNICAL INFORMATION

NAME	D3.F2
DESCRIPTION	Control switch – footswitch model
CONTROL SYSTEM	Compatible with the S3 control system
FUNCTION	Manoeuvring left/right or up/down
MATERIAL	Casing in glass filled nylon
COLOUR	Black

Design and material subject to change without prior notice

